

# Up and Down in a Flash!

- **Versatile, light and bright**
- **Waterproof fabric**
- **98% UV protection**



- 1** Remove the frame from the bag and open the shade half way.
- 2** Open the polyester roof and place it over the frame, be sure to align the length of the roof with the length of the frame.
- 3** Connect the corner straps of the roof to the top of the legs.
- 4** Connect the eyelet on the roof's overhang to the frame via the thumb-screw attachment. The thumb-screw is found on the top of each leg.
- 5** Attach the velcro pad in the centre of the shade's roof to the centre point of the push-up pole which has the opposite velcro pad to hold the roof in place. Make sure your roof is square on the frame.
- 6** With two people holding the opposite ends of the frame, pick the frame up and walk backwards to expand the shade open.
- 7** Lock the roof sliders into place by pushing upwards until the locking pin is in place.
- 8** Extend two legs on the same side until they lock into place. Do the same for the remaining two legs.
- 9** Select the height required by extending the legs further in or out using the three settings on the leg.
- 10** When using shade on a soft surface ensure legs are pegged down and guy lines are connected and pegged. On a hard surface ensure frame is weighted down.

***Your shade is now ready for use - enjoy!***

# ***CARE INSTRUCTIONS***

- 1** When travelling over any distance, we advise that you completely remove the roof from the frame. While being transported, the vibration of the frame against the roof can cause unnecessary damage to the fabric. If the shade is dropped or scuffed against a rough surface, you could sustain further damage to your roof.
- 2** Avoid packing your shade away when wet. This could damage your shade's shape and colour and shorten its lifespan considerably.
- 3** If using the shade on or near the beach, we advise that the shade be rinsed thoroughly after use. The legs can be completely removed, enabling easy access to hose inside to remove any residue sand.
- 4** To remove any marks from the polyester fabric, we recommend a product like Sard's Wonder Soap together with warm soapy water.
- 5** To remove any marks from the aluminium frame, we recommend mineral turpentine, or a metal cleaner for more stubborn marks. Please read cleaning product labels before use to ensure it is suitable for aluminium.
- 6** When folded, take care not to drop the shade on to its feet or roof. This may cause damage to the feet or corners of the frame/roof.
- 7** Avoid using your shade on windy days.

***Your shade has 12 months warranty protection against workmanship and manufacturing defects***